



## Forward Mount

- 1 Secure cable support bar to rear of side brackets, opposite from the rack mount tabs.
- 2 Slide UST1 or UMT8 between the two side brackets, at the front end near the rack mount tabs. The front of the UST1 or UMT8 should be flush with the front of the side brackets at the rack mount tabs.
- 3 Secure UST1 or UMT8 to side rack mount brackets with 3 screws on each side.
- 4 Secure entire assembly to rack at rack mount tabs.
- 5 Drape cables over cable support bar.

## Reverse Mount

- 1 Secure cable support bar to front of side brackets, near rack mount tabs.
- 2 Slide UST1 or UMT8 between the two side brackets, at the rear end opposite the rack mount tabs. The front of the UST1 or UMT8 should be flush with the back of the side brackets.
- 3 Secure UST1 or UMT8 to side rack mount brackets with 3 screws on each side.
- 4 Secure entire assembly to rack at rack mount tabs.
- 5 Drape cables over cable support bar.